ARDEX WPM 196

SBS Torch-Applied Tanking Membrane

PIPE PENETRATION DETAIL



FLASHING - REINFORCING RODS

STEP 1

Cut smaller diameter hole than Reinforcing Rod.



STEP 2

Rod is raised through smaller diameter hole in WPM 196, forcing edge upwards to create



STEP 3 Roll Patch down to eliminate void.



STEP 4

Form upstand with WPM 196 to rod.

