

## TECHNICAL BULLETIN – TB015

### APPLICATIONS FOR ARDEX K15M, K12N, ARDITEX NA & FEATHER FINISH OVER INTERNAL DRY TIMBER SURFACES & UNDERLAY SHEETS

Date, 25<sup>th</sup> August 2020.

#### INTRODUCTION & SCOPE

One of the most common problems in renovation and remodelling of existing buildings is the levelling and smoothing of wooden subfloors to receive hard floor coverings, floating floors, and carpet.

Wooden floors are often rough and uneven, with deviations from zero to several centimetres in three metres. Installing a hardwood, fibre cement, or MDF underlay sheet over rough/uneven timber will often result in disintegration of the underlay and floor coverings when exposed to traffic stress.

The resilient flooring standard AS1884-2012 states that;

#### **3.2.6.5 Particleboard subfloors**

*Resilient flooring shall not be adhered directly to particleboard subfloors. If the resilient flooring is to be adhered, an underlay or underlayment shall be used.*

#### SOLUTIONS

The following ARDEX underlayment applications can be used for vinyl, hard floor coverings, floating floors, tiles and carpet to provide a smooth and level surface. Herein K15M refers to K15 Microtec and K12N refers to K12 'New'.

OPTION 1 – ARDITEX NA FLOOD COATING DIRECT BONDED TO TIMBER . ARDITEX NA IS SUITABLE FOR STRIP T&G, PARTICLEBOARD, PLYWOOD.

Pre-levelling/smoothing/patching of the wooden flooring using ArditeX NA can provide a flat durable surface. ArditeX NA can be featheredged to meet existing floor heights.

Floor coverings (excluding direct stick timber) can be direct applied to the ArditeX NA, or underlay boards can be laid over pre-levelled/smoothed/patched area.

OPTION 2 – ARDITEX OR ARDEX K15M / K12N USED A PATCH WITH FIBRE-CEMENT SHEET, HARDBOARD OR MDF UNDERLAY SHEETS

Depressions in the floor can be filled with ArditeX NA or ARDEX K15M / K12N mixed with ARDEX E25 Improver and then over sheeted with underlay to provide a rigid and flat surface.

This is the preferred method for installation of ceramic tiles to minimise the risk grout cracking.

Refer to the adhesive and floor covering manufacturer's advice for application over wood based underlays.

### OPTION 3 – ARDEX FEATHER FINISH AS A SKIM COAT

ARDEX Feather Finish can be used on closely fitted fibre-cement underlay, plywood and particleboard flooring to fill in grooves, gouges, level up joints etc., and allows for the fast installation of floor coverings. Extra flexibility and adhesion can be achieved if the Feather Finish is mixed 1:1.5 with ARDEX P82 primer (itself already mixed correctly).

Application of Feather Finish over T&G board flooring is not recommended.

#### SUBSTRATE PREPARATION

***Note: Particleboard/plywood flooring is often coated with a resin protective layer. This resin layer may act as a bond breaker to applied finishes and must be removed by sanding.***

1. The wooden subfloors must be clean and free of oil, grease, wax etc. The subfloor should be solid and fixed to provide a rigid base, with deflections less than  $1/360^{\text{th}}$  of the span distance of the floor joints. Any boards exhibiting movement should be re-nailed and open joints should be filled with a suitable fast setting mortar.

The examination of the subfloor is a professional evaluation by the contractor and is most important.

2. Sand the wooden subfloor, using a coarse abrasive, to remove all foreign matter and to provide a mechanical surface for the installation of Arditec NA, ARDEX K15M / K12N or Feather Finish.

The attached photo is particleboard flooring sanded with 36 grit abrasive to produce a suitable textured profile clean of surface waxes and contaminants.



3. Subfloor shall be vacuumed to remove any dust or sanding debris.
4. Ensure that there is adequate cross-flow ventilation and that the minimum height clearance between earth and the timber flooring, in accordance with Australian Standards are maintained. Failure to have adequate ventilation can result moisture build up under the subfloor which result in excessive floor deformation, mould growth or moisture permeation through the underlayment which can result in blistering of sheet vinyl.

#### PRIMING FOR ARDITEX NA AND ARDEX K15 / K12N

1. Prime the wood subfloor with ARDEX P82 Ultraprime in accordance with the data sheet. A thin pink coat is sufficient and excess material will slow drying and create a rubbery surface which can result in cracking of the underlayment.
2. Drying time is a minimum of 3 hours (@ 23°C) and a maximum of 24 hours.

## INSTALLATION OF UNDERLAYMENTS

### OPTION 1 – ARDITEX NA FLOOD COAT.

Install ArditeX as per the technical data sheet, allowing the ArditeX NA to dry completely prior to installing flooring. This is typically around 24hrs, and can be extended at lower temperatures and high humidity

For thickness over 8mm, the minimum recommended temperature is 15-16°C.

Where underlay sheets are to be applied over the ArditeX follow Option 2 from 2.

### OPTION 2 – ARDITEX NA OR ARDEX K15M / K12N AS A PATCH AND DEPRESSION FILLER WITH FIBRE-CEMENT UNDERLAY SHEETING.

#### ARDITEX

All depressions and undulations to be filled with ArditeX NA Latex Self- Smoothing Cement

1. Allow the ArditeX to harden to walkability (2-4 hours). Install the fibre-cement underlay sheets as per manufacturers written instructions.
2. *Install Hardwood and MDF*  
Avoid joins of the underlayment sheets over any ArditeX patched area.
3. The underlay sheet must be secured to the wooden floor, using nails or sufficient length to penetrate through the ArditeX and lock into the wooden subfloor (see attached diagram). These nails should penetrate through the timber sheeting.
4. Touch up and fine finishing of fibre-cement underlay sheets can be achieved using ARDEX Feather Finish.

#### ARDEX K15M / K12N

1. All depressions and undulations to be filled with ARDEX K15 mixed with ARDEX E25 improver.

*Note: ARDEX K15M to be mixed with ARDEX E25 as follows:*

K15M	K12N
1.6 litres ARDEX E25	1.6 litres ARDEX E25
Plus 4.0 litres water	Plus 4.0 litres water
To 20 kg ARDEX K15M	To 20 kg ARDEX K12N

2. Allow the ARDEX K15M / K12N to harden to walkability (2-4 hours). Install the fibre-cement underlay as per manufacturers' written instructions.
3. Avoid joins of the underlay sheet over any ARDEX K15M / K12N patched area.
4. The underlay sheet must be secured to the timber floor, using long nails to penetrate through the ARDEX K15M / K12N and lock into the timber subfloor (see attached diagram). These nails should penetrate through the timber sheeting.
5. Touch up and fine finishing of the fibre-cement underlay can be achieved using ARDEX Feather Finish.

*Special Note: For Masonite and M.D.F. Underlayment installation, follow procedure as above with the exception of that the underlayments must be allowed to **dry completely** before applying Masonite and M.D.F. sheeting.*

### OPTION 3 – ARDEX FEATHER FINISH AS A SKIM COATING

1. ARDEX Feather Finish can be installed from a true featheredge up to 3mm thick.
2. Apply the mixed ARDEX Feather Finish to the clean substrate with a steel trowel. Fill all defects in the surface completely and apply sufficient pressure to the trowel to feather the product into the existing surface.
3. **As soon as the ARDEX Feather Finish can be walked on without damaging the surface (in as little as 15 – 20 minutes) vinyl tile & sheet and carpeting can be installed.**

## FLOORING ADHESIVES

ARDEX recommends the use of ARDEX AF 171 for;

- sheet vinyl
- vinyl planks
- Damtec Standard (2mm cork containing soundproofing). Use a V12 trowel
- Damtec Multi (4 mm rubber). Use a V2 trowel
- Regupol 4515
- ARDEX DS 40

Note : This adhesive has a fast grab and is also suitable for vertical applications.

ARDEX recommends the use of ARDEX AF 271 for;

- Vinyl backed carpet tile
- Non-vinyl backed carpet tile
- Vinyl composite tile
- For other carpet tile backing consult ARDEX


**NEXUS** flooring adhesives, when used in accordance with the product data sheets, are compatible and warrantable with ARDEX products so please visit <https://www.nexusadhesives.com.au/>. High quality tools, trims, profiles and profile accessories can be found at **DTA Australia** <https://www.dta-us.com.au/>.

## NOTES


*Always make a test installation first to assure success, as floor conditions vary from site to site and refer to flooring manufacturer and adhesive manufacturer for their recommended installation procedures.*

*This bulletin does not apply to wet areas as defined in AS3740 or floors requiring waterproofing systems under the BCA/NCC.*

*The practice of installing the liquid smoothing cements on the top of fibre-cement underlay sheets is not recommended. One problem is that dips and depressions in the fibre-cement sheet can result in problems with sheet cracking or damage. These sheets work best on already relatively flat surfaces. Also the underlay sheets are attached to the base timber boards, but still retain a fairly large degree of their flexibility and can be deformed. The higher strength smoothing cements can result in the edges of the sheets lifting, resulting in cracking of the topping at the fibre-cement joints, possible lipping and resultant show through. The only type of fibre-cement sheet that can have liquid smoothing cements directly applied is compressed fibre-cement sheeting.*



Typical application of Arditex NA or ARDEX K15M / ARDEX K12N + ARDEX E25 used as a patch below fibre-cement underlay sheets and ceramic tiles.



Typical application of Arditex used as a patch below fibre-cement underlay sheets for vinyl

## GLOSSARY

*Underlay* – The description used in AS1884 to describe fibre-cement, hardboard and MDF sheets used as sheets placed on subfloors under resilient flooring.

*Underlayment* – the description used in AS1884 to describe engineered liquid applied smoothing cements placed on subfloors under resilient and textile floor coverings.

ARDEX refer to these mostly as “levelling compounds”

### **IMPORTANT**

This Technical Bulletin provides guideline information only and is not intended to be interpreted as a general specification for the application/installation of the products described. Since each project potentially differs in exposure/condition specific recommendations may vary from the information contained herein. For recommendations for specific applications/installations contact your nearest Ardex Australia or Ardex New Zealand Office.

### **DISCLAIMER**

The information presented in this Technical Bulletin is to the best of our knowledge true and accurate. No warranty is implied or given as to its completeness or accuracy in describing the performance or suitability of a product for a particular application. Users are asked to check that the literature in their possession is the latest issue.

### **REASON FOR REVISION – ISSUER**

PERIODIC UPDATE AND INCLUSION OF NEXUS AND DTA INFORMATION

#### **Australia**

**Technical Services** 1800 224 070. email: [technicalservices@ardexaustralia.com](mailto:technicalservices@ardexaustralia.com)

**Customer Service and Sales** 1300 788 780

Web : [www.ardexaustralia.com](http://www.ardexaustralia.com)

#### **New Zealand**

**Technical/Sales Inquiries** 0800 227 339

Web : [www.ardex.co.nz](http://www.ardex.co.nz)

Web Corporate: [www.ardex.com](http://www.ardex.com)